

ALUMINUM TIE DOWNS

STEP

1

Choose your Front Tie Downs:

Does the truck have running boards that extend past the cab and onto the bed?

No

Yes

	YEAR	MODEL (CAB TYPE)	BED LENGTH	MFG#	MFG#
FORD	99-07	F250/F350 (All Cabs)	8'	F2011A	-
	99-07	F250/F350 (All Cabs)	6.75'	F2007A	-
	08-10	F250/F350/F450 (All Cabs)	8'	F2011A	-
	11-15	F250/F350/F450 (All Cabs)	8'	F2016A (27)	-
	06-14	F150 (All Cabs, No Bed Stepside)	6.5'	F2014A	-
	2015	F150 (SuperCab/extended) Super Crew	6.5'	F2018A	-
DODGE	03-09	2500 / 3500 HD (All Cabs)	8'	D2101A	-
	10-12	2500 / 3500 (All Cabs)	8'	D2115A	-
	2013	3500 (SRW) (All Cabs)	6.5'	D2123A	D2128A
	2014	2500 Gas Engine (Regular Cab)	8'	D2126A(28)	D2127A (29)
	14-15	2500 Crew Cab/Mega Cab	6.5'	D2126A(28)	D2127A (29)
	13-15	3500 (DRW or SRW)(Crew Cab)	8'	D2124A	D2127A (29)
	14-15	2500 Crew Cab	8'	D2126A(28)	D2127A (29)
	2014	3500 4wd Diesel Engine (SRW)(Mega/Crew Cab)	6.5'	D2123A	D2128A
	13-15	3500 4wd Diesel Engine (DRW)(Mega)	6.5'	D2125A	-
	2015	2500 (Crew Cab, Quad Cab)	6.5'	D2126A(28)	-
	2015	3500 4wd Diesel Engine (SRW) (Crew Cab)	6.5'	D2123A	D2128A
	2015	3500 Gas Engine (Regular Cab)	8'	D2124A	-
CHEVY	11-15	2500 / 3500 HD (Crew / Ext. / Double Cab Only)	8'	C2214A	-
	01-10	1500 / 2500 / 3500 Classic & New Body HD 8" Frame (All Cabs)	8'	C2204A(10)	-
	01-10	1500 / 2500 / 3500 Classic & New Body HD 8" Frame (All Cabs)	6.5'	C2205A(10)	-
	11-15	2500 / 3500 HD (Crew / Ext. Cab / Double Cab Only)	6.5'	C2220A	-

ALUMINUM TIE DOWNS

STEP

2

Choose your Rear Tie Downs:

If the vehicle has a rear hitch, please select which type of hitch

Factory Hitch

SuperHitch

	YEAR	MODEL (CAB TYPE)	BED LENGTH	MFG#	MFG#
FORD	00-11	Ranger (All Cabs)	6'	F3001A (15)	-
	81-97	F250 HD (Square Body)	6.5', 8'		R3503A (23)
	81-97	F350 HD (Square Body)	ALL		R3503A (23)
	97-03	F150 / F250 LD (All Cabs)(Round Body)	ALL	F3001A (15)	-
	99-04	F250 / F350 (All Cabs)	ALL	F3001A (15)	R3503A (1,23)
	05-10	F250 / F350 (All Cabs)	ALL	F3001A (15)	R3503A (1,23)
	05-15	F350/F450 / F550 Cab & Chassis (34" Frame Only)	N/A		R3503A (1,23)
	06-14	F150 All Cabs	ALL	F3005A	
	09-14	F150 (All Cabs/No Bed Stepside)	5.5' & 6.5'		R3508A (19)
	11-15	F250 / F350 (ALL Cabs)	ALL	F3001A (15)	R3503A (1,23)
	2015	F150 (All Cabs)	5.5' & 6.5'	F3007A	N/A
	2015	F150 (All Cabs)	5.5' & 6.5'	F3007A	N/A
DODGE	89-93	D150 / D250 / D350 (All Cabs)	8'	-	R3503A (14,20,21,23)
	94-02	2500 / 3500 (All Cabs)	ALL	-	R3503A (14,20,21,23)
	04-08	1500/all cabs	ALL	D3109A (8,11,14,20)	-
	03-12	2500/3500 (All Cabs)	ALL	D3109A (8,11,14,20)	R3503A (14,20,21,23)
	09-14	1500 (All cabs)	ALL	-	R3507A (19)
	13-15	2500/3500 (All Cabs)	ALL	D3109A (8,11,14,20)	R3507A (14,20,21)
CHEVY	88-94	1500 / 2500 (All Cabs)	ALL	-	R3503A (23)
	91-94	3500	8'	-	R3503A (23)
	95-98	1500 / 2500	ALL	-	R3503A (23)
	95-00	3500	8'	-	R3503A (23)
	99-13	1500 / 2500 Classic LD 5.5" Frame (All Cabs)	8'	-	R3503A (23)
	01-07	1500 / 2500 / 3500 Classic HD 8" Frame (All Cabs)	6.5'	C3205A	R3503A (1,23)
	01-07	1500 / 2500 / 3500 Classic HD 8" Frame (All Cabs)	8'	C3206A	R3503A (1,23)
	07-10	2500/3500 NEW BODY (All Cabs)	ALL	C3206A	R3503A (1,23)
	07-13	1500 New Body (ALL CABS)	6.5' & 5.5;	-	R3507A (19)
	07-13	1500 New Body (Standard & EXT Cab)	8'	-	R3507A (19)
	11-14	2500 / 3500 (ALL Cabs)	ALL	C3212A (13,21)	C3212A (13,21)
	2014	1500 (All cabs)	ALL	-	R3509A (19)
	2015	2500 / 3500 (ALL Cabs) SRW	ALL	C3215A	C3216A
	2015	3500 DRW	8'	C3217A	C3216A
	2015	3500 DRW	8'	C3217A	C3216A
TOYOTA	08-15	Tundra (All cabs)	All	-	R3507A (19)
	2014	Tundra (All cabs)	All	-	R3507A (19)